



Bothy INCA

Sara Abode
(Lakshadweep)

EXTERIOR-INTERIOR WOOD FINISH

Advanced polymer formulation, bridging performance with aesthetics

Tobslak Bothy INCA is suitable for a wide range of interior & exterior wood work applications including wooden floor. To seal and protect exterior wooden surfaces such as decks, outdoor/indoor wood furniture, wooden bridges, docks, garage doors, shutters, window frames, doors, garden furniture, gates etc.



buildwellcoatings@gmail.com

Dealer:

CHARACTERISTICS

- Non yellowing after UV exposure.
- Does not peel & blister.
- Low odour, Scratch & abrasion resistant.
- Self Priming and undercoating.
- Durable Protection.
- Flexible finish for all exterior wood.
- Tintable for various custom colour options.

Application Description:



STEP 01 CLEAN
Wood surface must be suitably prepared, clean, dry and free from traces of dust, dirt, wax and grease.



STEP 02 SAND
Sand surface in the direction of the grain to avoid damage on wood surface.





STEP 03 FILL
Choose similar or nearest wood filler, apply using filler knife or scraper, press firmly into place, smoothen with sandpaper on treated surface.



STEP 04 PRIMER
Apply 1 coat of Tobslak Bothy INCA and keep sanding with emery paper in between the coats, also allow to dry each coat before applying subsequent coat.



STEP 05 TOP COAT
Apply 1-2 coats of Tobslak Bothy INCA and keep sanding with emery paper in between the coats, also allow to dry each coat before applying subsequent coat.



Bothy INCA

EXTERIOR-INTERIOR WOOD FINISH



टिम्बर डेकिन के लिए नॉन-स्लिप वाटर बेस्ट कोटिंग

Bothy INCA लकड़ी के बोर्डों के लिए विशेष यूवी अवशोषक पानी के साथ एक जल आधार सतह रक्षक है। आईपीई, सागुडान, डगलस देवदार आदि से बने डेक के उपचार के लिए विशेष रूप से उपयुक्त है।



Sara Abode
(Uttarakhand)

उपलब्ध रंग



Light oak



Nut wood



Teak



Pine



Clear*

और रंगों में Chestnut, Chocolate, EC White and OP White भी उपलब्ध हैं।

#दिखाए गए शेड केवल संकेत उद्देश्यों के लिए हैं। वास्तविक रंग लकड़ी के प्रकार पर निर्भर हो सकते हैं।



buildwellcoatings@gmail.com

पॉलिश करने की विधि

1. पहले से पेंट या पॉलिश करी हुई लकड़ी-पुरानी पॉलिश या पेंट को पेंट रिमूवर और रेगमाल लगा कर उतार लें। कोरी लकड़ी दिखने लगेगी।
2. अगर कोई मरम्मत या भराई करनी है तो वुड फिलर या पुट्टी से करें। फेविकोल इस्तेमाल नहीं करें।
3. नई लकड़ी या उतारी हुई लकड़ी को 80/120 ओर फिर 400/600 (पानी वाला) रेगमाल से चिकाना कर लें। रेगमाल लकड़ी की रेशों की दिशा में ही लगाएं।
4. **पहला कोट:** पहला कोट अच्छे ब्रश से लगायें लकड़ी की रेशों की दिशा में। 3-4 घंटे सूखने दें। सूखने के बाद 1000 नंबर का पानी वाला रेगमार



से चिपकी हुई धूल हटा दें। रेगमार रेशों की दिशा में ही लगायें।



5. **दूसरा कोट:** पहले कोट की तरह अच्छे ब्रश से लकड़ी के रेशों की दिशा में लगा लें। 3-4 घंटे सूखने दें। सूखने के बाद 1000 नंबर का पानी वाला रेगमार से चिपकी हुई धूल हटा दें। रेगमार रेशों की दिशा में ही लगायें।

6. **तीसरा कोट:** दूसरे कोट की तरह लगायें। सूखने के बाद 1000 नंबर का पानी वाला रेगमार से चिपकी हुई धूल हटा दें। रेगमार रेशों की दिशा में ही लगायें।

7. डेक फ्लोर पर तीन कोट जरूरी हैं।

8. डेक फ्लोर या फर्श पर पानी रुकने न दें उससे झाड़ू से निकल दें।

